









XM125 Test

Taehun Kim
bigteach0508@pusan.ac.kr
Embedded Systems Lab.
School of AI, PNU
2025. 03. 12

Contents

-  Schematic
-  Installation
-  GUI results
-  CLI installation
-  CLI results
-  Conclusion

Schematic

✚ Sparkfun XM125




Figure 1. Sparkfun XM125

Schematic (cont'd)

+ XM125 block diagram




Figure 2. XM125 block diagram

Schematic (cont'd)

A121

- 1 Tx antenna and 1 Rx antenna
- Serial Peripheral Interface(SPI) communication with MCU




Figure 3. A121 block diagram

Installation

- + Install CH340 driver
 - <https://www.arduined.eu/ch340-windows-10-driver-download/>
- + Download Acconeer Exploration Tool
 - https://developer.acconeer.com/download/portable_exploration_tool/
- + Double click the update.bat file and the run_app.bat





Figure 4. Acconeer Exploration Tool

Installation (cont'd)

- ✚ Flashing firmware
 - Click the flash menu
 - Click Get latest binary – Get latest bin file
 - Register at <https://developer.acconeer.com/register/>
 - Download the firmware
 - Click the flash button to flashing firmware



The screenshot shows a web interface for downloading and flashing firmware. At the top, there are two tabs: "Browse" and "Get latest binary", with the latter being the active tab. Below the tabs, there is a "Get latest bin file" button and a text input field containing "25_exploration_server_a121-v1_9_0". To the right of the input field is a "Clear cookies" button. Below these elements, there are three dropdown menus: "Serial" (set to "COM4"), "COM4 0" (set to "0"), and "XM125" (set to "XM125"). At the bottom, there is a large "Flash" button.

Figure 5. Download the firmware

Installation (cont'd)

- ✚ Baud rate setting
 - Click the setting(cogwheel) button
 - Setting the baudrate to 115200




Figure 6. Setting the baudrate

GUI results

Sparse IQ




Figure 7. Sparse IQ

GUI results (cont'd)

Distance detector




Figure 8. Distance detector

GUI results (cont'd)

Presence detector




Figure 9. Presence detector

GUI results (cont'd)

Speed detector




Figure 10. Speed detector

CLI installation

- ✚ Get example source code
 - <https://github.com/acconeer/acconeer-python-exploration/tree/master/examples>
- ✚ Double click the cmd_with_path.bat in portable_exploration_tool
- ✚ Set client information
 - Serial port and baudrate
- ✚ Run the source code
 - python examples/a121/basic.py

```
client = a121.Client.open(  
    # ip_address="<ip address or  
    # or  
    # serial_port="<serial port  
    # or  
    # usb_device=True,  
    # or  
    # mock=True,  
    serial_port='COM4',  
    override_baudrate=115200  
)
```

Figure 11. Serial Configuration


CLI results

- Basic.py
 - print real parts and imaginary parts of the receive signals
 - Sweep_per_frame x num_points

```
C:\Users\WESLAB\Desktop\xm125\portable_exploration_tool>python examples/a121/basic.py
Server Info:
ServerInfo:
  rss_version ..... a121-v1.9.0
  sensor_count ..... 1
  ticks_per_second ..... 1000
  hardware_name ..... xm125
  max_baudrate ..... 2000000
  sensor_infos:
    SensorInfo @ slot 1:
      connected ..... True
      serial ..... None
Result 1:
Result(data_saturated=False, frame_delayed=False, calibration_needed=False, temperature=13, _frame=array([[(-178, 241), (-174, 179), (-191, 221), (-228, 146), (-291, 113),
(-220, 64)],
[(-129, 240), (-79, 203), (-191, 163), (-275, 95), (-255, 96),
(-277, 12)],
[(-216, 142), (-152, 130), (-218, 176), (-266, 98), (-285, 36),
(-224, -34)],
[(-131, 209), (-178, 246), (-239, 207), (-262, 29), (-258, 81),
(-270, 55)]], dtype=[('real', '<i2'), ('imag', '<i2')]), tick=1555, _
context=ResultContext(metadata=Metadata(_frame_data_length=24, _sweep_data_length=6, _subsweep_data_offset=array([0]), _subsweep_data_length=array([6]), _calibration_temperature=15, _tick_period=0, _base_step_length_m=0.00250227400101721, _max_sweep_rate=8902.890625, _high_speed_mode=True), ticks_per_second=1000))
```

Figure 12. Real and imaginary part of signals

CLI results

 basic_plot.py





Figure 13. I/Q scatterplot

CLI results (cont'd)

 basic_plot.py




Figure 14. real and imaginary value by sweep and distance point

CLI results (cont'd)

Basic_plot.py




Figure 15. real and imaginary heatmap by sweep and distance point

CLI results (cont'd)

Basic_plot.py

$$\text{Amp} = \sqrt{I^2 + Q^2}, \text{Phase} = \arctan \frac{Q}{I}$$




Figure 16. real, imaginary, amplitude, phase heatmap by sweep and distance point

CLI results (cont'd)

basic_plot.py




Figure 17. Amplitude and phase value by frame and distance point

CLI results (cont'd)

Plot_analog.py




Figure 18. plot I/Q data, magnitude heatmap, phase heatmap, and I Q line plot

CLI results (cont'd)

 `Plot_analog.py`




Figure 19. plot magnitude, phase, i_values, q_values after flattening signal

CLI results (cont'd)

 plot_analog2.py

distance point of sweep 1




Figure 20. Distance point of sweep 1

CLI results (cont'd)

 `plot_analog2.py`




Figure 21. Sweep of distance 1

CLI results (cont'd)

Distance measurement

- Modify `examples/a121/algo/distance/processor.py`

```
C:\Users\WESLAB\Desktop\m125\portable_exploration_
mples\m125\algo\distance\mprocessor.py
qt.core.qobject.connect: QObject::connect(QStyleH
tion of a QObject subclass
Press Ctrl-C to end session
distance: 0.307347947699052
distance: 0.31169640669684523
distance: 0.30788424648690377
distance: 0.3124415844453782
distance: 0.31049557093571317
distance: 0.3108571014046115
distance: 0.31328463547220003
distance: 0.3182344253138537
```




Figure 22. Distance measurement

CLI results (cont'd)

Speed measurement

■ Modify examples/a121/algo/speed/processor.py

```
C:\Windows\system32\cmd.exe - python C:\Users\WE...
k.destroyed.disconnect()
Disconnecting...

C:\Users\WESLAB\Desktop\xm125\portable_examples\
a121\algo\speed\processor.py
qt.core.qobject.connect: QObject::connect(
tion of a QObject subclass
Press Ctrl-C to end session
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : -0.4460237661272241
current speed : -0.4360062542436704
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : 0.0
current speed : -0.4897751174773545
current speed : 0.0
current speed : 0.0
current speed : 0.0
```




Figure 23. Speed measurement

CLI results (cont'd)

- ✚ Sparse IQ
 - Modify `example/a121/algos/sparse_iq/sparse_iq.py`
 - Range-doppler heatmap
 - ▶ Range: from $\text{start_point} \times 0.0025$ to $\text{start_point} \times \text{step_size} \times \text{num_points}$
 - $\text{Step_size} = \text{step_length} \times 0.0025$
 - ▶ Velocity: $\pm \text{wavelength} / (4 \times \text{sweep_period})$
 - $\text{Sweep_period} = 1.0 / \text{sweep_rate}$
 - $\text{Step_size} = \text{sweeps_per_frame}$




Figure 24. Range-doppler heatmap of result 0

Conclusion

- ✚ XM125 sensor cannot measure the Angle of Arrival(AoA) because it has only one Rx antenna
- ✚ Analog data may not be directly extracted from the sensor
- ✚ However, digital signal $I + Qj$ can be extracted from the sensor of sweep and distance point
- ✚ Using the complex number, amplitude and phase can be calculated
- ✚ Heatmap can be created from the digital signal
- ✚ Distance and speed data can be calculated

References

Manual

- XM125 datasheet
- XM125 schematic

Online

- <https://github.com/acconeer/acconeer-python-exploration>
- https://docs.acconeer.com/en/latest/exploration_tool/api/a121.html
- <https://matplotlib.org/stable/users/index.html>
- <https://matplotlib.org/stable/gallery/mplot3d/index.html>

Appendix

- Acconeer software offers
 - Service output is radar data with some pre-processing
 - Detector output is based on service output but uses further processing to create a result such as a distance or presence detection




Figure 25. Acconeer software offers

Appendix (cont'd)

Custom Range FFT




Figure 26. Range FFT

Appendix (cont'd)

Custom range-doppler heatmap




Figure 27. Range-Doppler FFT heatmap